



RELEASED  
12/2/22

PPP

Part Number	K10112
Description	Saddle Kit for D206-642-112/-114

Box Part Number	N/A	Dimension	N/A
Other Packaging	Foam	L x W x H	
Logo Decals			

### Packaging Instructions and Decal Placement

#### K10111

Place kit in D206-642-112/-114 box. Place some more foam on top to prevent movement.  
Add hardware and saddle. Seal box and apply label D2729-3 as per instructions in QSI 014 section 4.5

**Note: Fill all voids of box with foam to prevent movement.**

D2729-1

D2729-3

N/A

	<b>Dart Aerospace Ltd.</b> 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
<b>K10112 SADDLE KIT      CHG003</b>	
<b>INCLUDES PARTS FOR:</b>	
<b>D206-642-112</b>	<b>CHG007</b>
<b>D206-642-114</b>	<b>CHG002</b>
<b>B/N: BXXXXX</b>	

Revision: G
Date: 12.01.30

H:\Admin-qa\iso\forms\PPP-1.Rev.A